

Transformadore tipo **Poste Trifasico J** ANCE (Voltaje en Baja 220/127V)



POSTE TRIFASICOS CONVENCIONAL NORMA J (VOLTAJE EN BAJA 220/127V)	UOM	CLAVE GENERICA (CONTINENTAL)	CLAVE IG
15KVA - 3-OA-132000 - 220/127 V. J	PZ		H061N0
30 KVA - 3-OA-13200 - 220/127 V J	PZ	TPOST30KV132J-AN	H051N0
45 KVA - 3-OA-132000 - 220/127 V. K	PZ	TPOST45KVAJ	H052N0
75 KVA - 3-OA-13200 - 220/127 V K	PZ	TPOST75KVAJ	H053N0
112,5 KVA - 3-OA-132000 - 220/127 V. K	PZ	TPOSTE112.5J	H054N0
30 KVA - 3-OA-23000 - 220/127 V K	PZ		N218N0
45 KVA - 3-OA-23000 - 220/127 V. K	PZ		N219N0
75 KVA - 3-OA-23000 - 220/127 V K	PZ		N217N0
112,5 KVA - 3-OA-23000 - 220/127 V. K	PZ		N220N0